

Dear Customer,

we have available a new version of poly flex resin, whose code is T 90 and hardener K 95.
This edition requires the oven for drying, as it doesn't catalyze at room temperature.

INSTRUCTIONS TO FOLLOW CAREFULLY FOR T90 RESIN WITH HARDENER K95

- . Store spare cans, cartons or pallets at ambient temperature.
- . Work in an air-conditioned environment, humidity max 50%, optimal conditions also for the storage of cans to be used for the mixture.
- . Mix resin and hardener with Vacuum Poly Mix C80 for 5 minutes.
- . **For the drying of the T90 resin customers have to use the oven for 6h at 40 °** (resin doesn't dry at ambient temperature).
- . **RATIO MIX 1:1**
- . Resin T90 and hardener K95 are not compatible with any other leftovers of previous supplies with different reference codes.

We suggest to do the usual tests before making the production.

| WORKING WITH OVEN |
|--|
| Store cans to be used for the mixture at ambient temperature 22° or more |
| Have at least 22° during working time |
| Dry in 6 hours at 40° |

Best regards,
Manicardi srl